

TRANSFER VIEW INSTALL

=====

Requirements

IBM PC or compatible (Pentium or better)
Microsoft(R) Windows(R) XP / Vista / 7 / 8

Install

Run setup.exe

Warning

1 - After the Install, the option "Save settings on exit"
and the language "English" are notched by default.

2 - "The version number of the driver of the USB adapter must be equal at least
to 6,5.

In the case of a first use, verify if the driver of the USB adapter / optical
serial has been installed.

If it is not, start by installing the driver. "Please run the program to install
the USB driver that is located at :

- For Windows XP ,: \\driverusb\\Windows_XP_S2K3_Vista_7.
- For Windows 7 and 8 ,: \\driverusb\\CP210x_VCP_Windows.

Then, follow the procedure:

- Switch off the instrument.
- Close the application.
- Let USB cable between PC and device.
- Start the device on 'SET- UP' position.
- Run application.