








9153038

Guide de démarrage rapide (FR) / Quick Start Guide (GB) / Schnellstart-Anleitung (DE) / Guida di avvio rapido (IT)/ Guía de inicio rápido (ES) / Handbok för snabbstart (SE)/ Stručná úvodní příručka (CZ) / Pikaopas (FI)/ Snelstartgids (NL)/ Skrócona instrukcja uruchomienia (PL)/ Ghid de inițiere rapidă (RO)/ Краткое руководство пользователя (RU)

V	Ω	$\xrightarrow{\Omega} \leftarrow$	ALARM Ω
  50.2 Hz 23.17 V_{AC} •••••	  205 mA 0.43 Ω •••••	  207 mA 0.13 Ω •••••  207 mA 0.00 Ω $\xrightarrow{\Omega} \leftarrow$ •••••	 ALARM < 200 Ω 0.43 Ω •••••

MΩ	MΩ Lock		P
